

## Wren Wall Mount Bracket

### Tools Required

Depending on application:

- Cordless Drill with magnetic post and a #2 Phillips tip
- Tape measure
- Drill bits for wall fasteners

### Hardware Required:

- Wren wall mount bracket
- Screw cover caps (2)


### Installation Note:

*Kimball International defines a structural wall as a load-bearing wall constructed of materials such as: wood or metal studs. Wood studs must be a nominal 2" x 4" size minimum. Metal studs must be "C" channel, 20-gauge thick minimum. Metal or wood studs must be on centers no greater than 24" and have maximum height of 14' restrained at floor and ceiling. Interior walls shall be designed to resist not less than a force of 5 lbs. per square foot applied perpendicular to wall. The deflection of such walls under a load of 5 lbs. per square foot shall not exceed 1/240 of the span for walls with brittle finishes, and 1/120 of the span for walls with flexible finishes (per Uniform Building Code Section 2309b). If you have any questions concerning your load-bearing structures, please consult your architect or structural engineer.*

Note: Hole sizes are dependent on size of fastener selected.


Recommended Fastener	Size
Steel Stud (for 1/2" to 3/4" drywall):	Panhead sheet metal screw #10 x 2"
Wood Stud (for 1/4" to 1/2" drywall); meets or exceeds ANSI/ASME B18.6.4 and SAE J933	Panhead sheet metal screw #10 x 2"

Figure A




Wall Mount Bracket

Figure B



Screw Cap Covers

Figure C



### Installation:

1. Place wall bracket (Figure A) on wall at desired height being sure that bracket is centered on a stud inside of the wall structure. Mark the bracket screw holes with a pencil. Drill placement for wall fasteners.
2. Insert the fastener into the screw covers (Figure B), then place the screw cover onto the bracket (Figure A) and attach to wall. Close the screw cover caps to conceal screw heads and prevent scratching the chairs.
3. Fold chair and hang on the bracket using the bottom edge of the chair back.